KONKR Pocket FIT
User Manual

For model of KONKR Pocket FIT

KONKR Pocket FIT

KONKR

KONKR
POCKET FIT

Navigation Button
Open the in-game or application menu. Functionality depends on software optimization and supports customization.

6"LCD Display

Custom Function Button
By default, it switches performance modes and supports user-defined function settings.

Left Joystick
Hall-effect joystick for controller input.

A, B, X, Y Buttons on Controller

Left Joystick Ambient Light Ring
Default color: cyan-white, supports color customization.

Right Joystick Ambient Light Ring
Default color: cyan-white, supports color customization.

Directional Pad (D-Pad)

Directional Pad (D-Pad)

View Button on Controller

= Button
The default function is to return to the desktop,and custom settings are supported.

Menu Button on Controller

K Button
AYAWindow Main Interaction Button, Short press to bring up the Quick Settings window for adjusting device performance, fan speed, controller settings, and other functions. Long press to enter the AYASpace homepage.

Left Speaker

Right Speaker

Note:The functions of the AYA button, ">" button, controller buttons and joysticks, menu button, and custom function buttons, as well as the joystick ambient lighting color settings, are subject to updates in the latest versions of the AYAWindow and AYASetting applications.
Please note that some button functions may vary depending on third-party application compatibility.

Power Button / Fingerprint Sensor
Controls power on/off and sleep mode, supports fingerprint recognition.

Charging Indicator Light
Power-on Status: The white light stays on during startup and turns off after the boot animation begins. Charging Status: The orange light stays on while charging. When the battery reaches 100%, the white light stays on. The indicator turns off after unplugging the charger.

RC Custom Function Button
Default function: "Back" (supports customization).

LC Custom Function Button
Default function: Opens Task View (supports customization).

RB Button

LB Button

RT Button
A trigger button supporting linear input.

LT Button (Left Trigger) on Controller
A trigger button supporting linear input.

Volume Adjustment Button
Adjusts system volume.

Microphone Pickup Hole

Active Cooling Exhaust Vent
The fan pressurizes air, dissipating heat from the processor through the heatsink fins and expelling it to ensure optimal performance.

Note： The functions of the LC, RC, and custom buttons may vary based on updates to the AYAWindow and AYASetting applications. Please refer to the latest versions of these apps for accurate configuration.

RT Gear Switch
Two-position toggle switch to change between linear mode and button mode.

LT Gear Switch
Two-position toggle switch to change between linear mode and button mode.

AYANEO

Active Cooling Air Intake
The cooling fan draws in cool air, circulates it internally, and expels heat through the exhaust vent.

RC1 Button
Supports custom configuration of controller combination keys.

LC1 Button
Supports custom configuration of controller combination keys.

Dust Cover / Micro SD Card Slot
Supports installation and replacement of Micro SD storage cards.

USB-C Port
Supports PD fast charging, USB 3.2 Gen 2 data transfer, and DP 1.4 video output.

3.5mm Headphone Jack
CTIA standard, compatible with MIC expansion.

Microphone Pickup Hole

KONKR Pocket FIT
User Manual

For model of KONKR Pocket FIT

Size 211×84mm

Power on / Power off / Restart

Power On
When the device is powered off, press and hold the power button " ___ " for approximately 3 seconds, then release. The AYANEO Pocket Fit will start up.

Power Off
When the device is powered on, press and hold the power button " ___ " for about 2 seconds until the menu appears on the screen. Select " ⏻ " to turn off the AYANEO Pocket Fit.

Restart
When the device is powered on, press and hold the power button " ___ " for about 2 seconds until the menu appears on the screen. Select " ↻ ", and the AYANEO Pocket Fit will reboot.

Sleep / Wake up

Sleep Mode
When the device is powered on, briefly press the power button " ___ ", and the AYANEO Pocket Fit will enter sleep mode.

Wake Up
When in sleep mode, briefly press the power button " ___ " to wake up the AYANEO Pocket Fit. If a screen lock is set, you will need to draw the security pattern or enter a password/PIN to complete authentication before accessing the system interface.

Fingerprint recognition

Fingerprint Recognition Setup
To use the fingerprint recognition feature, you must first set up a screen lock:
1. Go to " ⚙ "Settings > " 🔒 "Security & Privacy > "Set Screen Lock".
2. Choose a lock method: Pattern, PIN, or Password, and follow the on-screen instructions to complete the setup.

Fingerprint Enrollment
After setting up the screen lock:
1. In the "Security & Privacy" menu, select "Device Unlock" > "Fingerprint".
2. Enter the previously set Pattern, PIN, or Password for security confirmation.
3. Follow the on-screen instructions to enroll your fingerprint and complete the setup.

Note: After powering on or restarting the device, you must verify the screen lock security by entering the Pattern, PIN, or Password before using fingerprint unlock. All operations and icon functions are subject to the actual interface and on-screen prompts.

Volume

Volume Adjustment
Press the volume up button " ___ " to increase the volume step by step. Press the volume down button " ___ " to decrease the volume step by step. Long pressing either button will continuously adjust the volume.

Volume Settings
Go to " ⚙ " Settings> " 🔊 "Sound & Vibration to adjust media volume, notification volume, alarm volume, and more.

Text Input
When text input is required, tap on the input field to automatically bring up the on-screen touch keyboard. Use the touch keyboard to enter text.

Dropdown Menu
Swipe down from the top of the screen to open the dropdown menu, allowing quick access to settings such as internet, Bluetooth, and more. You can also adjust the screen brightness using the brightness slider.
Swipe down again to reveal more quick settings. Tap " ✎ " to customize the quick toggle options as needed.

Network / Bluetooth
The AYANEO Pocket Fit supports WLAN network connections and Bluetooth device connections.

Network Connection
Go to " ⚙ "Settings > " 🛜 "Network & Internet Icon > " 🌐 "Internet Icon.
Under the WLAN section, select the network you want to connect to, enter the corresponding password, and connect to the WLAN network.

Bluetooth Connection
Go to " ⚙ "Settings > " 🖥 "Connected Devices.
Tap " ＋ "Pair with New Device, select the Bluetooth device you want to connect from the search list, and follow the on-screen instructions to complete the connection.

Storage Expansion
The AYANEO Pocket Fit is equipped with a Micro SD card expansion slot. Open the dust cover at the bottom of the device to install or replace the Micro SD card.

📇 micro SD

Data Transfer
To connect to a PC for data management, after connecting the AYANEO Pocket Fit to the PC, go to " ⚙ "Settings > " 🖥 "Connected Devices > " ⛙ "USB.
Under the USB Usage section, select "File Transfer" to enable proper data transfer.

Software Upgrade
To enhance the AYANEO Pocket Fit user experience, AYANEO will regularly push system software updates. You can check and install system updates by following these steps:
1. Go to " ⚙ "Settings > " ℹ "About Device > "System Update".
2. On the System Update page, tap "Check for Updates". If a new version is available, follow the on-screen instructions to upgrade and enjoy the latest system features.

Note: A WLAN network connection is required in advance, and the network should remain stable during the update process. Ensure that the device has sufficient battery power, or connect to a power source to prevent unexpected interruptions during the upgrade.

More Features
The AYANEO Pocket Fit offers a variety of personalized feature settings, which can be managed through AYASetting, including:
● Account: Manage AYANEO personal account information and synchronization services.
● Performance: Adjust device performance modes based on your needs.
● Controller: Configure button mappings and controller functions.
● Personalization: Adjust system wallpaper, quick settings window, and other customization options.
● Device: Options for screen, fan, screen casting settings, and more.
● Updates: Perform updates for AYAWindow, AYASetting, AYAHome, AYASpace, and controller firmware.

Note: Specific settings and features may change with updates to the AYASetting app. Please refer to the actual version for accurate details.

Usage Notice
Before using this product, please read all instructions and specifications carefully. Incorrect usage may cause internal component damage or potential safety risks to personal health.

● Operating System
AYANEO Pocket Fit runs on the Android operating system and can be operated via touch controls.

● Charging
When charging, please use a safety-certified adapter. Do not use uncertified adapters, as they may cause damage to internal components and pose unpredictable risks. AYANEO Pocket Fit requires a charger that supports PD PPS. To ensure stable charging, it is recommended to use an adapter that supports PD 3.0 PPS 20V 5A, along with the included USB-C cable.

● Battery Replacement Warning
Do not attempt to replace the AYANEO Pocket Fit battery yourself. Doing so may damage the battery, causing it to overheat and potentially lead to fire and personal injury. The lithium-ion battery should be serviced or recycled by AYANEO or an authorized service provider. It must be separated from household waste for proper disposal according to local environmental regulations. Replacing the battery with an incorrect model can cause explosion risks.

● Thermal and Noise Notice
During use, the product may generate heat and fan noise, which is normal. Actual temperature and noise levels may vary depending on usage performance. You can switch performance strategies by pressing the Turbo button according to your environment and needs.

● Software Updates
Please refer to the software updates pushed by AYANEO for the latest software features.

● Cleaning
Use a lint-free cloth to clean the product. Avoid using any chemical solvents or abrasives.

● Environmental Protection and Recycling
Do not disassemble the product yourself. It must be disposed of separately from household waste. Please follow local environmental regulations for recycling.

● Protection
Avoid dropping, crushing, or bumping the device, as it may cause physical damage.

● Accessory Variations
Some accessories may vary depending on the purchased configuration and country or region.

● Medical Device Interference
The internal components of the AYANEO Pocket Fit contain magnets and electromagnetic fields that may interfere with medical devices, pacemakers, defibrillators, or other medical equipment. Please maintain a safe distance between the AYANEO Pocket Fit and medical devices.
Consult your physician and medical equipment manufacturer for information. If you suspect the AYANEO Pocket Fit interferes with your pacemaker, defibrillator, or other medical equipment, stop use immediately.

Warranty Service
AYANEO provides a warranty for the hardware products and accessories included, effective for one year from the date of original retail purchase. The warranty does not cover normal wear and tear or damage caused by accidents or improper usage. To request service, please visit the official AYANEO website or an authorized service provider. Available service options may depend on the country or region where the service request is made and may be limited to the original country or region of sale. Additional charges, such as phone or international shipping fees, may apply.
When you submit a valid claim under the warranty service policy, AYANEO will, at its discretion, provide repair, replacement, or refund services for your AYANEO Pocket Fit. Your warranty rights are supplementary to those provided by local consumer laws. When submitting a claim under this warranty policy, you may be required to provide detailed purchase proof.

Support
For more support and troubleshooting information, please visit www.ayaneo.com.

Names and Contents of Hazardous Substances in the Product

Part Name	Hazardous Substance					
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
PCB Components	✕	○	○	○	○	○
Plastic Parts	○	○	○	○	○	○
Metal Parts	✕	○	○	○	○	○
Power Cables	○	○	○	○	○	○

This table is compiled according to SJ/T11364 regulations.
○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirement specified in GB/T26572.
X: Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirement specified in GB/T26572.
Note: This product applies an environmentally friendly design concept and effectively controls hazardous substances. The "X" indicates that the hazardous substance is primarily due to the limitations of technological development, making substitution of the hazardous substance impossible.

♻ 10

Environmental Protection Use Period
The symbol indicates the period (ten years) during which the hazardous substances contained in electronic and electrical products will not leak or undergo abrupt changes under normal use conditions. During this period, the use of these electronic and electrical products will not cause severe pollution to the environment or cause serious harm to the user's health and property.